

Oven / Grill Cleaner Premium

DESCRIPTION & BENEFITS

Oven/Grill Cleaner Premium is a clear thin liquid. This product is an outstanding oven and grill cleaner that effortlessly cuts through the toughest food soils, grease, oil and other food deposits, thus reducing cleaning times. This product is suitable to clean ovens, grills, hoods, fryers, other cooking equipments and kitchen floors.

Oven/Grill Cleaner Premium has a low odour formula and can be used neat or diluted to suit your application. This product is fast and effective. This product is not suitable for use on decorative surfaces, chrome or aluminium.

- ✓ Highly concentrated formula
- ✓ Heavy duty
- ✓ No harsh scrubbing required
- ✓ Solvent free

DIRECTIONS FOR USE

1. Remove excess grease, fats and carbonised deposits with a scraper or other suitable implement and rinse with water.
2. Spray Premium Oven /Grill Cleaner undiluted directly onto equipment and leave the surface wet for 1-3 minutes.
3. Wipe off the residues with an absorbent cloth and rinse off with water when clean.

CAUTION: This product is HIGHLY ALKALINE and CORROSIVE. Avoid contact with skin and eyes. Wear suitable gloves and eye/face protection. Do not mix product with hot water.



Code No 405

ENVIROMENTAL ASPECTS

- ✓ PF- Phosphate Free
- ✓ Safe for food processing areas & septic tanks when used according to dilution instructions

PRODUCT AVAILABILITY

This product is available in 20 L, 15 L and 5 L.

SAFETY INFORMATION

Consult us for specific use directions and SDS. For service and additional information please contact us on **1800 201 700**